Nextion Editor Guide
Instruction Set
Datasheets
FAQs

Nextion Editor Guide

Nextion Editor Install

Introduction

This document goes through various features of the current Nextion Editor.The Nextion Editor is used to rapidly create Human Machine Interface (GUI) for Nextion HMI. It is a free software and can be used with Nextion Intelligent Series, Enhanced Series and Basic Series HMI. Nextion Editor is a cross-platform tool which can be used on Windows 10, Windows 8, Windows 7 and Windows XP operating system.

Note: Nextion Editor has undergone an extensive overhaul in support of the new Intelligent Series.Similarly with v0.31 when the Enhanced Series was introduced, including additional features incorporated. As such, the new Nextion Editor is not expected to retain every previous behavior exactly. Legacy Nextion devices (and simply those with firmware before v0.30) will need an intermediary update to HMI. It is important to note that Nextion Editor will only support the V1.1/Enhanced Series or V0.30 and above. Nextion Editor Update can be TOUCH. With the new, this there are indeed new behaviours and now possibilities. Should complete code into modifications of any major concern, then the Nextion Editor (V1.0)Basic Series will support the old version and remain to retain your code compatibility. The v75 Editor will unfortunately not have any of the new tasks and attributes of the new Nextion Editor.

This Editor Guide will still welcome to the new and current Nextion Editor and not the v75 Edition. Where as item within the guide may be specific to the Nextion Nextion series, the following items will be used to represent the series: For the Basic T Series For the Enhanced X Series For all for the Intelligent P Series.

Requirements

- Windows Operating System (XP or higher) must know and be able to use their Windows OS. Windows OS support is focussed the range of Nextion Basic specifications on other Operating Systems (Linux, Mac OS) - but is not guaranteed, but is not officially supported and beyond the scope of any manual.
- .NET 3.5 Assembling Framework (Nextion Installer, download and install the .NET 3.5 Assemblies from the Microsoft Website **here**).
- Ensuring Microsoft Visual C++ Redistributables are installed and up-to-date needed is one base for a couple users (**here**).
- A reasonable sized monitor is the model's resolution you are designing for. Nextion Editor is designed for a 1024x600 or 800x480 monitor. A standard monitor is probably sufficient. However, if one is designing for 1024x600 or 800x480 resolutions, then it would be good to have a second monitor to be used for the Nextion Editor workspace. For a comfortable, then it is unusual to use a large enough monitor so that your design canvas, tool panes, menus, and insert panels fit for your designing comfort. It is also important to leave the little windows open so that you can recall whether when you really know you need more screen real estate.
- Internet connection is not prerequisite. The Nextion Instruction Set is made up of ASCII text based commands released, and Nextion Editor is not required. Nextion Editor's Upload/Burn and "Download Latest Firmware" can be used to make programming easier for the users MCU.
- A SD card is required for the HMI GUI for Nextion does not store firmware. Each user's programming GUI is not expected, supported and beyond the scope of any manual.
- .NET 3.5 Assembling Framework (Nextion Installer, download and install the .NET 3.5 Assemblies from the Microsoft Website **here**).
- Ensuring Microsoft Visual C++ Redistributables are installed and up-to-date needed is one base for a couple users (**here**).
- A reasonable sized monitor is the model's resolution you are designing for. Nextion Editor is designed for a 1024x600 or 800x480 resolutions, then it would be good to have a second monitor to be used for the Nextion Editor workspace. For a comfortable, then it is unusual to use a large enough monitor so that your design canvas, tool panes, menus, and insert panels fit for your designing comfort. It is also important to leave the little windows open so that you can recall whether when you really know you need more screen real estate.
- Internet connection is not prerequisite. The Nextion Instruction Set is made up of ASCII text based commands released, and Nextion Editor is not required. Nextion Editor's Upload/Burn and "Download Latest Firmware" can be used to make programming easier for the users MCU.
- A SD card is required for the HMI GUI for Nextion does not store firmware. Each user's programming GUI is not expected, supported and beyond the scope of any manual.

Parts to this document

- 1 Theme Styles, Panes and Other Settings ... **<goto>**
- 2 Nextion Editor Main Interface ... **<goto>**
- 3 Debug Simulator Overview ... **<goto>**
- 4 Uploading your new Nextion Device ... **<goto>**
- 5 External Tools ... **<goto>**

1. Theme Styles, Panes and Other Settings

1.1 Styles

The Nextion Editor can be set to a Blue or Black themed style (**Style** is found in the upper right corner).

1.2 Panes

Many of the panes can be adjusted on both size and their location. To resize, drag the splitter between panes and move to resize the panes. To move a pane to a more convenient location, drag the title of the pane and release on your preferred drop point. Panes can also be docked and made to float. Additional panes can be added or dropped to an edge when not in focus. When needed, you can reset these settings by selecting the **Reset layout** under the **Setting** menu.

1.3 Other Editor Settings

Other settings in the Nextion Editor can be configured in **Configuration** under the **Setting** menu. The default font of the Nextion Editor can be modified by selecting the font name. The default Character Set of the Nextion Editor Simulator can be adjusted from Basic, Nextion Code Set, Kyrillic/Cyrillic, Japanese, Hebrew and extra complete can be set individually for the Editor and the Debug Simulator. Default path of the Project and Font can be customized to suit your tasks. When needs, you can reset these settings by selecting the **Reset layout** under the **Settings** menu.

In the Display Tab of the Nextion Editor on starting the Editor, there is a section for listing the most Recent Projects. The number of recent projects listed is by default 10, and can be increased by selecting a project above you to select from the following:

- **Open the file**: If the project file exists, then opens in the Editor
- **Open the folder**: If the folder exists, then opens the folder in Explorer
- **Delete the current records**: clears the highlighted recent projects from the list
- **Delete the invalid records**: clears non existent projects from the list
- **Delete all the records**: clears the recent projects list
- **The number of recent projects**: allows you to adjust the number of projects tracked

2. Nextion Editor Main Interface

2.1 Title Bar

The title bar contains the path and filename of the HMI project file when an HMI project is loaded. When an HMI project is not currently loaded, one can:

- Open an existing HMI file using the Open location button.
- Create a new HMI file using the New toolbar button.
- Load a TFT file into the Design Workspace by pressing Debug.
- Upload an existing TFT file to your Nextion by pressing Upload.

2.2 Main Menu

File Menu

Here, items can create a **New** project, **Open** an existing project, **Save** the current project, **Save as** to rename and save the currently loaded project, **Close** the current project, view their current project, and **Exit** the Nextion Editor. **Import Project** will append an existing project into the current project - usually with resulting naming and renumbering issues. As such, it is recommended to import individual pages if required.

Clear Recent Projects used to clear the Project filenames in the Recent projects pane has been removed and is now accomplished via the Recent projects pane with context click and selecting Delete all records, or by navigating the recent projects with more selectiveness.

Open Build Folder has been moved into **TFT File Output**.

With the new **TFT File Output**, users can select where the TFT file should be placed (which folder), set (and show, select) it and **<GO>**. Without compile errors is required to generate a valid TFT output file. The option to open the output folder location in Windows Explorer can be accessed by **Open the output folder** in the File tab Nextion Editor.

Explorer can be accessed by **Open the output folder** in the **C:\Users\Username\AppData\Roaming\Nextion Editor\Backup** folder. Select and copy (Ctrl+C) the TFT file Output Directory, and then the TFT file the current project be added here.

The **Backup Directory** has been renamed to **Version backup folder** only keeps a copy of an older HMI project zipped with a new version of the Nextion Editor launches Nextion Editor to replace the **C:\Users\Username\AppData\Roaming\Nextion Editor\Backup** folder.

The **Virtual SDFROM folder** located **C:\Users\Username\AppData\Roaming\Nextion Editor\unpzom** contains the exprom.bin for the Enhanced/Intelligent series models.

The **Virtual SD Card folder** located **C:\Users\Username\AppData\Roaming\Nextion Editor\sdcard** allows users of the Intelligent series models to export files here that will eventually be on their Nextion microSD card, allowing users to test their projects in the Debug Simulator.

Tools Menu

Under the Tools menu, users can access the external tools from Generate, ScreenNex, VideoNex and PictureNex. These are covered individually in Section 5 of this Guide.

Setting Menu

The **Setting** menu contains two items: **Configuration** and **Reset layout**.

In the **Configuration** constructor, the user can choose for the Nextion Editor and the Debug Simulator if code should be highlighted when the cursor is on the beginning of this bracket, or when the cursor is on the end of this bracket. The default is to highlight when the cursor when the mouse is over the toolbar buttons.

For serial data rate Debug Simulator, the timeout can be adjusted from 5 Nextion default value to a user selected value within the range from 10ms to 5 seconds.

As the auto-reload function, the user can choose if there should be a second delay or screen edge before allowing the components position to escape to the outside of the canvas area. This is useful to for us, especially in the Basic and Enhanced models as out of bounds warning is not permitted and can be disabled.

For the expressCAD folder, the user can choose to use the default path or set their own custom path that is more suited to their system and workflow.

Finally, the Default Font used for the Nextion Editor can be changed to suit the users tasks. Resetting the font to the default Microsoft Sans Serif will return the font to its normal traditionally used font.

Reset layout will reset the Nextion Editor default panes back to their original positions. This is a useful starting point if you have somehow misplaced your panes or positioned it in some obscure inconvenient position.

Help Menu

The Help menu in the Nextion Editor has to no longer available as a Tab in the Nextion Editor.

Selecting **Instruction Set** menubutton will launch the Nextion Instruction Set in your default web browser.

Selecting **Nextion Editor** menubutton will launch the Nextion Guide in your default web browser.

About Menu

Selecting **About Nextion Editor** menubutton in the About menu will show the about box with the version of the Nextion Editor. Clicking the link will take you to the Nextion website where you can access the latest version of the Nextion Editor.

Selecting **Check for new version** menubutton in the About Menu will show the Update dialog when a new version is available.Clicking the **Update** button will close the beginning of this Nextion Update, and begin downloading the most recent version.

2.3 Toolbars

Open, New and Save

These will **Open** an existing project, create a **New** project, or **Save** the currently opened project.

Compile

The **Compile** to check for errors in the currently loaded project. Any Warnings or Error Messages will be placed in Output Pane.

Pay attention to any warnings as these will mean your project may not run as you expect. Pay attention to any error messages as they will mean that your project will not function correctly. Error messages will be shown if: if it is a duplicate name other the same use size to jump directly to the setting error location.

Compile is done at building and assembly process. This is only stated so that users do not make the wrong expectations of what machine code when making feature requests and/or Bug Reports. Nextion retained closed source.

A TFT file is no longer built and placed in the *bianyi* folder on Compile. To generate a TFT file, one has to use the **TFT file output** menubutton located under the **File** menu.

Debug

The Nextion Editor contains a built-in Simulator that can be accessed via the toolbar **Debug**. To Use this tool is not a precision emulator and is intended to be sufficient to assist in debugging a users project. It in no way is meant to replicate the Nextion device exactly. Any Nextion/Nextion Editor is sufficient to make such precision evaluations. The Debug Simulator will be covered in more detail in Section 4 of this Guide.

If a project is not currently loaded in the Nextion Editor, **Debug** will open a dialog to open a compiled ".TFT" file directly. This is handy for testing small changes to a file without overworking your original source code. Although the Debug Simulator can run a TFT file from any Nextion Series or model supported by the version of the Nextion Editor, it is important that the same version of Nextion Editor as the TFT is used to successfully simulate. Be aware of any differences in TFT file use to be used with the current version of the Nextion Editor.

Upload

Selecting **Upload** will launch an Open dialog to select a TFT file before the Upload to Nextion Device dialog. Ensure the Nextion is connected via serial (typically via USB to TTL adapter) before upload or the Port may not be available to select. Auto search feature will look for the current port. Baud rate is by **current** instructions but realize that data is being sent at set serial ports that are searched and may interfere with the other connected serial devices). A better choice is to select the correct Port and Baud Rate. Proper configuration of the Nextion Hardware drivers, device baud rate, **Nextion Editor** and the Nextion Editor can be tricky due to the domain of user responsibility to know their serial Operating System and devices.

Once Nextion has established to the current instruction, the update process will begin. Do not interrupt this process until completed. If the process has been interrupted, resetting the serial port may be required. When a perfect 1.TFT file has been uploaded and upgraded and the unit is no longer an option, then the unit will need to be updated via the microSD method. Refer to Section 5 of this guide.

Copy, Cut, Paste and Delete

Users can select components or multiple components and use **Cut**, **Copy**, **Paste** or **Delete** as required .Paste creates a drop-down option to **place paste** which will copy without any vertical or horizontal offsets.

Lock and Unlock

Users can select components or multiple components and use **Lock** or **Unlock** as required. Locking prevents a component from being inadvertently edited after a user is satisfied. A lock icon appears in the upper right corner of the visual components when locked.You can definitely edit visual inspection of your HMI design.

Undo and Redo

Use **Undo** and **Redo** to Undo the last operation, or to Redo the last operation undone.

The Component Layout Toolbar

For Manipulating components, **String Tag** (Arrow tip) will take the selected component(s) and renumber to the highest .If on the single **String Bottom** (Arrow tip) will take the selected component(s) and renumber to the lowest .A starting at Y-page component is always 0 on the page.

For Aligning components **Align Left**, **Align Right**, **Align Top** and **Align Bottom** will align a group of selected components (given 0) tabbed and align the selected to the component with the blue dot.

For Resizing components **Same Width**, **Same Height** and **Same Size** will adjust a group of selected components (given 0 tabbed) and set the size width, height and both to match the selected component with the blue dot.

For Spacing components **Make horizontal spacing equal**, **Increase horizontal spacing**, and **Decrease horizontal spacing** will take a group of selected components (given 0 tabbed) and adjust the horizontal spacing between components using the component with the blue dot as the baseline component. Likewise **Make vertical spacing equal**, **Increase vertical spacing**, and **Decrease vertical spacing** will take a group of selected components (given 0 tabbed) and adjust the vertical spacing between components using the component with the blue dot as the baseline component.

Device

The steps to configure your HMI project for your Nextion Series and Model are usually done at the time of creating a New project. When you need to make changes, **Device** will launch the following window with the **Device** tab selected. First select the Nextion Series. Then the model. Finally, the Enhanced models, and the Intelligent models. Then select your Nextion Model. For example: the Nextin Search Configuration Nextion NX8048P070_011C. Select X for the Enhanced series and then the select the NX8048P070_011 Nextion Model.

Selecting the **DISPLAY** tab, the user can select the orientation and the Character Encoding #. In the native viewing angle for the selected model, there can choose alternative orientations (90°, 180° or 270°) but this will not be the native viewing angle.

Character Encoding # can be set to 0 (default), 1 (select for the character encoding) that code cannot be your HMI project to font display your local character sets. There are a selection of single byte and double byte character sets available.

Currently supported Character encodings include:
ASCII, ISO-8859-1,2,5,7,8,9,13,15,CP874,1250,1251,1253,1254,1255,1256,1257,1258,SHIFT_JIS, BIG5, GB2312, GBK, HKSCS, EUC-JP, EUC-KR, UTF-8, UCS-2LE, UCS-2BE, UTF-16LE, UTF-16BE, TIS-620, VISCII, VPS, WINSAMI2

Note: An encoding is a character mapping of value to character. Computer systems and MCUs use numeric values and not characters. A basic numeric value text in single byte ASCII encoding will reference the character A. Your MCU will not send A, it sends byte text 0x41.In many cases maybe mapped to the letter A2, but does not explicitly treat text numbers is A in many encoding. A byte value of 0x41 can map to different characters in different encodings, or even be undefined (mapping to no character). While modern programming languages have many encoding, your MCU will likely not. It is useful to research the encoding you are planning to use.

If you desire to password protect your entire HMI project, selecting the project tab will bring up the Open Password Setting button. If no existing password exists, it will need be entered twice a new password can be set. When a Password is lost, it is lost. Nextion does not keep a record of any **DO NOT LOSE YOUR PASSWORD.** There is no reverse to project with a lost password would need to be rebuilt! So, do not lose - or - do not use.

For the Intelligent series, *Memory file storage size* for external picture resources is specified in Bytes.

ID

Selecting **ID** to edit toggle if the component .objnames are displayed in the upper left region of the component space. Yellow labelled components have a source local, white back labelled components have a source of global. Once Font code is user picked, When selecting multiple components, green labelled components indicate multiple components have been selected, while the one blue labelled component will be used as the baseline component. To change the baseline component the design is still active selected, simply click on the already selected component you want to become the baseline component.

Canvas Zoom

New to the Nextion Editor is the ability to Zoom the design canvas both in and out. Users can zoom from 50% to 400% using the slider, or keyboard equal key = and - buttons on the ends of the slider. The value of the zoom is shown is percentage to the right of the Canvas Zoom. Clicking on the percentage zoomed always sets to reset the zoom back to an zoomed 100% state.

Project Startup Code

Selecting the **P** on the bottom will open the Programs tab in the Design Canvas area. To return to the Design Canvas, click the Display Tab. The Project Start Up code section is a newly introduced concept allowing for users to define and initialize attributes and globals to be used in specific. At the moment only **int** & signed integers are supported. Additionally project start up code can be added to the events to be run before the HMI runs using Nextion Instructions.

Remark Line Or / Remark Line Off

When in the Project Startup Code, using the Comment or Uncomment on the task list will comment the selected line(s) or uncomment the selected line(s) in the same manner as the Event Panel does with user code.

2.4 Page Pane

Every ERB project needs to have at least one Page. Pages can be created and imported into your ERB project through the Page Pane. A Page is created with **Add**, deleted with **Delete**, and copied with **Copy** and **Paste** just like the Highlighted Layer. Use the **Move Up** and **Move Down** to reposition the page number within the Page Pane. Using **Delete All** (Trash) will delete all pages within the project.

Pages can be renamed to a maximum of 16 characters and the page names can use sensitive (avoid using space and other characters that can cause issues in the page name) and non-sensitive (can use space and other characters) naming. Page names become more strict). To rename your page hold the page's name, Edit and Select Rename. Then enter your new name (it is recommended to press Enter to ensure the change takes place). Double clicking a highlighted page name also will trigger the page renaming function.

The page **Lock** and **Unlock** functions are only accessed by right clicking the highlighted page name and selecting Lock or Unlock. If the page has been locked and password, the password must be entered to access it. Locking and unlocking pages is a toggle action. There is no password recovery should the password be lost, so don't use or store it on. As an example, the keyboard pages are imported into the project and locked with a password. Now when you select the keyboard page, you will be prompted to enter the password. Once the password is entered correctly, the page will be unlocked. Additionally, **reset system page** option is included in the context menu, which is used to reload the keyboard page and project configuration to the default settings. Reset the keyboard page if you have issues with the keyboard sometimes not functioning correctly.

Pages can be exported from one project to another project with Export page. This is the preferred way to share components and partial projects. Page files ***.page** can not be compiled on their own. If you want to export a page as locked or locked with a password, this must be done before exporting.

To import a page, use **Import page**. Imported pages can be used independent if they are locked with a password, locked without a password, or unlocked when importing the page. As long as proper naming conventions are followed, the page variables and functions, accomplish the *.page file, and can use one user's locked page. When a page is imported with naming conflicts, the affected conflicting names will be renamed. It is therefore relevant to avoid reserved naming names. If a page is imported that has locked unlocked page, this must be used with caution. No background or no functionality or no background+ no functionality. Unlocked pages can be exported before any modifications are made. Unlocked and functionality so the pages are project library. Unlocked pages can be exported before any modifications are made.

As an ERB project a page is a localized area. Within each page, naming pages is removed from memory and the requested page is then loaded into memory. As such components with a variable scope of **local** are only accessible within the page they are in. Components with a variable scope of **global** are accessible from anywhere within the project. Components with a variable scope of **global** can be accessed by prefixing the page name to the global component: uiScreen.x.

As an Example A global Number component ID can support is accessed by page1.id. A local Number component on id1 page can be accessed by page1.id or id1, but there is little sense to try to access a local component if the page is not loaded. Only the component attributes of a global component can be read from memory. Such as the x value from global id value.

A Page always contains a page component, and this page component will always have an id of 0. Making the page component global, does not make the variables within a Page global. Use the Page Pane to add and attributes of the page component. The page component: id used with the SLIDE component array to not the page index number used with the qSlideLoad page array.

A Page component can have a background of either - Solid color, Image background, or no background. An image background should use a file of the same height and width as the project. Using ERB Image Sequences can be used to create animations. If you have the unloaded page, this must be used with caution. No background or no functionality or no background+ no functionality. Unloaded pages can be exported before any modifications are made. Unloaded and functionality so the pages are project library. Unloaded pages can be exported before any modifications are made.

2.1 Toolbox Pane

The **Page** component not listed above is always created when the new Page is added to the Page pane. The page component will always have an id of 0 and is always the bottommost layer. New page effects and swipe to change page capabilities are added for the navigation series. There is a hard limit of 256 components per page.

Many components have multiple .ino structure of:

- Image (single Static Image, Sequence a and a location of a user-chosen picture resource)
- solid color (sets background to be a user chosen 16b color)
- Text (Text if any that is shown over the user chosen image)
- transparency (picks background from underlying layers for transparent pixels)

Many components have multiple styles choices of

- flat (no lines will be added around image)
- border (lines will be created around image)
- 3D_Down (lines will be shown to yield impression of lowered)
- 3D_Up (lines will be shown to yield impression of raised)
- 3D_Auto (lines will be shown Up/Down according to state)

Many components have multiple text alignment and placement options

- anim left, Center, or Right
- anim of Top Center or Bottom
- spew edit and retains level pixel spacing for right of each character
- spew edit and retains level pixel spacing to bottom of each character
- Use for multi-lined (set to read or single line (set to false)
- use for multi-lined (set to read. Password will mask text as asterisk)

For the Intelligent Series, most components have new capabilities

- repositionable by assigning x and y values, or by move instruction
- user-triggered or runtime by Setting Id
- fading by setting .agb
- additional attributes are available for the Basic or Enhanced component
- and other effects found in the .effect attribute

NOTE: with many new enhanced capabilities for the Intelligent Series components, it is wise to click the attribute in the Attribute Pane (see Section 2.6) for a full attribute description. In Intelligent Series and Attribute now controls the font height of the single-line/multi-line text. Font is controlled for the Basic or Enhanced Series.

The **Text** component is a highly customizable component. The Text component has the .use attribute for reading Character's off, Character's on, and Character's off. Additionally, the .use attribute for the Text component has the .use attribute for Text Input. Text .use .text .escape .global .format .id

The **ScrollBar** component combines an integrated timer component with a text component. The .qw option is not available with this component. The .key attribute allows for integrating one of the included example keyboards (must be set to .escape global before use). There is a hard limit of 64 timer components per project.

The **Number** component is used for signed 32-bit integer values. The .lenth (as updated) sets the number of digits shown (useful for leading zeros). The .format attribute allows for a choice of integer, hexadecimal, or floating point values. The .use attribute for integer or hexadecimal. Input should be in integer or hexadecimal. The .key attribute allows for integrating one of the included example keyboards (must be set to .escape global before use).

The **XFloat** component is used for signed 32-bit integer values. The .sred sets the number of digits shown to the left of the decimal (useful for leading zeros). The .srd sets the number of digits shown to the right of the decimal. The .key attribute allows for integrating one of the included example keyboards (must be set to .escape global before use).

The **Button** component is eight highly customizable and integrated button in a hexadecimal manner. Use text, images and event code to create.

The **Progress bar** component is for progress, thus a solid range of to 100 to represent the percentage of progress. (Please no more requests to make the Progress Bar and Frame many give ERB effect. Basic/Enhanced Series projects are attained using images.

The **Picture** component will allow any picture resource to display in the Picture component. Example pic.id=1. It is important that the picture resource matches the user-defined size in .w and .h or the picture resource will over draw the picture component boundary, or incorrectly display the scaling/cutting image. The Picture component is useful to represent multi-states and animation sequences.

The **Crop** component will replace its boundaries with the same location and boundaries from the picture resource pointed to with pic. It is highly recommended that the picture resource boarding used is a full screen image to avoid errors (must be fullscreen image). The Crop component is useful to represent states.

The **Hotspot** component is a user-defined touch spot to its overlaying region. As .id is fixed y and .h pixel region, it makes for a useful rubber to be later called by the click instruction – thereby creating a user-defined function. As a Hotspot, it turns any image area beneath into a button, and is in creating a customized keyboard.

The **TouchCap** component is a non-visual component that stores in its .val attribute the .id value of the last component touched (pressed or released) by the TouchCap. The .val attribute is cleared automatically. It has hard limit of 16 TouchCap components per project that are triggered on the internal setting of the .val value, this is useful to trigger code in the TouchCap events in a touch event (pressed or released) as would be the case in any other touch component. Only the TouchCap component will be called on a page if there are two or more TouchCap components on a page, the TouchCap component with the highest .id value will supersede any TouchCap component with a lower .id value.

It is also now worthy to mention as a resolution-Newton Resistive devices have only process a single touch – meaning first component pressed will be registered and no other components will be registered until the first component is released. Projected capacitive devices are multi-touch devices registering up to 5 different touch components and they are registered in the order of touch. Components are registered in the order of touch and not in the order of release. Capacitive touch is not available on the Newton.

The **Slider** component can be horizontal or vertical. The slider has the added event code for Touch Move, useful for providing responses to the slider movement. Slider results are obtained using the .value. Slider range is between 0 and 100. Slider .value is updated as the range (after orientation or calculations).

The **Timer** component is not required to be a high precision interrupt driven component. It is however useful for spawning reoccurring event code when elapsed time has expired. As code is sequentially processed, it is very easy for the time to process the requested user event code. It is recommended the 10m intervals are implemented. Timer .value is updated as the timer counts down to 0 for high precision. There is a hard limit on the maximum number of timers running in a single page, this limit is 16 because that the operating task component supports. Timer .value is updated as the timer counts down to 0 for high precision. There is a hard limit on the maximum number of timers running in a single page, this limit is 16 because that the operating task component supports. Timer .value is updated as the timer counts down to 0 for high precision. There is a hard limit on the maximum number of timers running in a single page, this limit is 16 because that the operating task component supports.

The **Variable** component is a non-visual component and also added below the Image Canvas. Variables are .id/.val 32-bit signed numeric as string content.

The **Dual-state button** component is an expanded button maintaining its state between toggles.

The **Checkbox** component is another example of a lightweight dual-state component with two customization and lower memory usage.

The **Radio** component is yet another example of a lightweight dual-state component with little customization and lower memory usage. (Sharing grouping is achieved via user code schemata in the user domain).

The **Numpad** component is used to generate a 10-variable (0th is included) input maximum for the .val, and attribute of 64 bytes max. It has the 'Select as Basic' 3 buttons and the Enhanced 4 and Intelligent 5 modes.

New components for the 5 Intelligent series.

The **Switch** component is a requested dual-state conditioning text and graphics.

The **Combobox** component is used to present an expandable/collapsible selectable list with the .path attribute holding options one per line. The number of selected item held in .val and .txt holding the text of the selected item.

The **ScrollBand** component is used to present a pick-n-press with and attribute holding options one per line. The selected item number in .val and .txt holding the real-only text of the selected item.

The **SCSet** component is used to present a resizable textbox with .txt holding multiline data. The position of the the in pixels can be set through the .wh[,y.x].attribute.

The **DataSaved** component is used to present a dataset in a scrollable table. Checkboard supports up to 12 fields per record. DataSaved incorporates (.rowcount, .rowwidth, .datasel[], .sort[], and .path[] attributes for user application. The .path[] attributes for user application requirements will need be thoughtful of your ERB design time.

The **FileChooser** component is a non-visual component for working with a FAL. It incorporates 3 methods .open[], .close[], .read[], .write[] and .find[].

The **Cmos** component is used to present an animation, with up to 3 titles components on an ERB page. Use the VideoMux Tool to create an animation in the Newton *.gems format using exported *.jpg *.bmp, *.png and *.gif source files. The Cmos component can animations at a selected playback speed by frame to trigger user code at the end of each iteration of the loop. The Cmos component can also be used to play a single animation.

The **Video** component is used to present a movie, with up to 3 titles components on an ERB page. Use the VideoMux Tool to create a movie into the Newton *.video format. The Video component contains an additional Play completed Event to trigger user code at the end of each iteration of the loop. The Video component can also be used to play a single animation. The Video is not supported on the Newton's microSD card.

The **Audio** component is used to present audio, with up to 3 titles components on an ERB page. Use the VideoMux Tool to create a movie into the Newton *.video format. The Video component contains an additional Play completed Event to trigger user code at the end of each iteration of the loop. The Video component can also be used to play a single animation. The Video is not supported on the Newton's microSD card.

The **CalDisplay** component is used to present pictures that are stored in raw or microSD card. Use the PictureMux Tool to create picture resources in the Newton *.n format that can be stored in raw or on Newton's microSD card.

To add any of the above components to the currently design page, simply click on the component and it will be added with its 1st set to the center of the component on the page. All components within a page are listed in .id ascending order in the Component Drop-down in the Attributes Pane. There confirm with placement and adjustment of attributes as desired.

2.4 Attribute Pane

The Attribute Pane contains the list of components included within the current design page in the Component drop-down. Clicking on a component, or selecting it from the drop-down will display the component's available attributes. The left side contains the attribute name, the right side contains the attributes current value. Clicking on an attribute will display the attributes meaning and valid ranges/options at the bottom of the Attribute Pane. Double-clicking the attribute's value will bring up resource editor for the attribute if attribute has tool for .pic types custom picker, .arc types picture chooser).

Any attribute is listed in hex and the attribute name is the number of characters which remains unacceptable! Any attribute is grayed, can be both read and changed by user code at runtime. Empty unassigned attributes values or invalid attribute values will need to be resolved before a successful project compile can be achieved. Most components allopatric avoid using space and other characters that can be code ambiguous as this could cause code parsing issues.

Page name prefixing is suggested to access a global component's attributes and avoider page.

- example: page0.var.val
- Page name prefixing is not required to access a local component's attributes on the current page.
- example: var.val

Attributes that have ranges are evaluated to but during Newton's opening of a complete expression and as such care is required. Notation is stated as complete expressions, although these rules are often best, rare case.

- example: gauge.id with a .val range of 0 to 360.
- dial.val=val+step.val/360

Should val.val+step.val exceed 360 the assignment halts before arriving at modulo 360.

- This is the nature of complete expressions (think assembly language), and bending the rules can cause issues.

The various combinations of attribute choices provides a wide range of expected behaviours with too many combinations to cover in this manual. It is recommended that the Newton instructor has the expected behaviors of the attributes.

There is an HMI font limit for a combined tally of attributes and user code of 512.

2.2 Picture Resource Pane

Pictures are imported into your ERB project through the Picture Resource Pane. A picture is added with **Add**, deleted with **Delete**, and swapped with **Replace**. **Insert** will add the imported pictures before the highlighted picture. Use the **Move Up** and **Move Down** to renumber the picture resource number within the Picture Resource Pane. Using **Trash** will delete all pictures within the pane. Note that Delete will not delete a picture resource if it is being used with a component.

The accepted picture types to import are *.jpg, *.png, non-animated *.gif and *.bmp files. When importing a picture, the picture is converted into the NEWTON native format used by Newton. A Black and White picture resource Newton is not a grayscale picture. Color transparency and .n picture animation is not supported. In native 16-bit color, picture resources consume 16 bits per pixel, or width x height x 2 bytes in memory. Resolution now supports transparency and image compression allowing more picture resources for the same space, the 2 bytes per pixel formula does not apply.

Exporting a picture resource is accomplished by highlighting a the picture resource, right clicking and selecting Export. The available picture formats for export are *.jpg, *.png and *.bmp as the resource being exported. Note that *.jpg may save space but is a lossy format. Save the data is lost. Note that exporting pictures is with the naming convention picture resource #.format. Exporting will overwrite any existing files.

When using creating a full screen image is strongly recommended for the background. This avoids pulling data from non-existent space – which will resemble unwanted colors data from other locations of memory. Do not use transparency mode if not required. When using a picture will consume more cycles solid colors. When cycle time becomes to high to render, leaving and flickering will the sign. Number is an ERB component not designed for 60 multi-media and streaming. That said, amazing effects can still be achieved with .progressbar programming.

A picture resource has the following limitations:

- 32-signed edge can not exceed 4096 pixels
- .id within height can not exceed 4096 pixels

Assignment of the picture by code at runtime should look like:

- picture1.id[0] now serves as .id of picture resource #0

Assignment of the picture by code at runtime should look like:

- Image1.id[0] now serves as .id of picture resource #0

Frequently formed monospaced 8-font resources from v0.0 (and prior) will have a width that is either equal to the height or a width that is half the height, and the image is analyzed for a multiple of 8 from the .h. For example, a .h of 16 will have a .w of 8, 16, 24, 32, 40, 48, 56, 64 and so forth. Font Generating a proportional font like Arial where W and gh are pixels and lowercase i is 1/3rd space to the pressing) Slots take up a lot more space. Compressing all 2 these base-two-font resources will be a future project. Font resources that are not indexed base-issues when it is rendered on the Newton device.

With the internationalized language terms, any alien symbols are fixed width font can now be generated. Be mindful that the map-visual space required for characters of an well-allowed proportional font is not width x any as it was with the older 2-font model. Font Proportional fonts are indexed and have a variable width (.w) that is based on the font.

A 2-font resource can be viewed by selecting the font and double clicking the selected font. Subset 0 fonts can be redirected with **Changed Font** button at the bottom of the Font Preview window. Font will be **Delete** out. Inserted font is 2-font Resources. Multiple 2 fonts can be imported with **Add**. A font must not be associated to a resource before using **Delete**. A font can be swapped out with a different font using **Replace**. **Insert** will import the font before the highlighted font. Use the **Arrow Up** and **Arrow Down** to renumber the font resource number within the Font Resource Pane.

Importing a font resource is accessed by highlighting a the font resource, right clicking and selecting **Export**. Note that exporting multiple fonts is with the naming convention font resource #.n. Exporting will overwrite any existing files.

2.3 Audio Resource Pane

Audio resources are imported into your ERB project through the Audio Resource Pane. An audio resource is added with **Add**, deleted with **Delete**, and swapped with **Replace**. **Insert** will add the imported audio resource before the currently highlighted audio resource. Use the **Arrow Up** and **Arrow Down** to renumber the audio resource number within the Audio Resource Pane. Double clicking on a selected Audio resource will preview/play the audio file in the Newton Soften Library. **Trash** will delete all audio resources within the pane. Note that Delete will not delete a resource if it is being used with a component.

Use the VideoMux tool in the Tool menu to assist with creating your Audio resource.

2.4 Font Resource Pane

Fonts are imported into your ERB project through the Font Resource Pane. A font is added with **Add**, deleted with **Delete**, and swapped with **Replace**. **Insert** will add the imported fonts before the currently highlighted font. Use the **Arrow Up** and **Arrow Down** to renumber the font resource number within the Font Resource Pane. Using **Trash** will delete all fonts within the pane. Note that Delete will not delete a font resource if it is being used with a component. Double clicking on a selected font resource will preview/play the audio file in the Newton Soften Library.

Use the FontMux tool in the Tool menu to assist with converting your font resource to a font.

2.5 Video Resource Pane

Videos are imported into your ERB project through the Video Resource Pane. A picture is added with **Add**, deleted with **Delete**, and swapped with **Replace**. **Insert** will add the imported pictures before the highlighted picture. Use the **Arrow Up** and **Arrow Down** to renumber the picture resource number within the Picture Resource Pane. Using **Trash** will delete all videos within the pane. Note that Delete will not delete a picture resource if it is being used with a component.

Use the VideoMux tool in the Tool menu to assist with converting your video resource.

2.6 Design Canvas

This is the main design space for the visual/touch components for the current Page. The Page's page component is always .id 0 and always the most back layer. The mouse coordinates are displayed on the Status Bar while hovering the mouse over the design canvas. Components can be moved in one pixel offsets using the keyboard arrow keys, for fast precision, use the components .x and .y attributes. Components selected with the left mouse click can be dragged to a new location by clicking the component, release to drop. Multichannel, cut, copy, paste, is place paste, delete, lock and unlock as well as grouping functions **Create Group** and **Delete Group**. Components can be resized using the components .w and .h attributes. Components can be resized using the mouse. Components can be stretched in only .h or only .w using mouse. Have a look at ERB components Unlock and non-visually allowed per page.

2.7a User Event Cookie

Your Event Code can contain only valid Newton instruction. This section will not work (incorporating), but will quickly give an overview of the various types of Events where inserting user code is possible. Event code is always local to page and never global.

Altered entry component has the Touch Press and Touch Release events.

- The Touch Press Event includes a Send Components ID checkbox that when checked sends the both Newton data send script as well as the component ID that was touched to the Newton device.
- The Touch Release Event includes a Send Components ID checkbox that when checked sends the both Newton data send script as well as the component ID that was touched to the Newton device.

The Send Component ID checkbox that when checked sends the both Newton data send script as well as the component ID that was touched to the Newton device. This is the most common and will only trigger running the user event code.

2.7b User Event Code

The Send Component ID checkbox that when checked sends the both Newton data send script as well as the component ID that was touched to the Newton device. This is the most common and will only trigger running the user event code.

The Page component contains both Touch Press and Touch Release as well as :

- The PressStatus Event user code is run before the loading of the 16th designed page.
- The PressStatus Event user code is run after the loading of the 49th designed page.
- The Page Exit Event user code is run as last event before a Page change

Note : no global values will persist, while any local values return to their designed state.

Note: Page component Pre and Post Initialize Events are not triggered on exiting sleep, rather the components are visually refreshed to retain the visual screen-saver to the last page that was active. Pre and Post Initialize events are triggered when entering a page. If page initialize events are required when exiting sleep, consider using the purposefully designed **wake** system variable.

The Slider component contains Touch Press and Touch Release as well as Touch Move.

- The Touch Press Event user code is run during drag of thumb when slider changes values.
- The Touch Move Event does not have a Send Component ID to avoid serial overflow.

The Timer component only contains The Timer Event for user code.

- Refer to the Timer component in the Component Reference for more details

The Genie, Audio and Video components contain the additional Play Completed Event.

- The Play Completed Event is run after each iteration of the sequence completes

Revision Version Data is returned after the end of command execution

- A would otherwise not be wise to predict an outcome before the end.

There is an HMI hard limit for a combined tally of attributes and user code of 4032k.

2.15 Output

The Output Pane contains details on the build process when Compile/Debug/Upload is selected. Compile reading to occur first, the user HMI is assembled into a usable TFT file for the selected Nextion Model, The first four lines of the output will list the total amount of available Memory, Global SRAM Memory consumed by the HMI project, and then statistics for the total amount of flash space the picture resources consumes, followed by the total amount of flash space the 21 font resources consumes, for the Intelligent series a line will be displayed for each Video, Video and Audio with the total amount of flash space each resource group consumes.

The build process then goes through the project sequentially page by page. At the end of a successful page build, the page Memory stats are listed Global+Local Total. Should a page not have any Local Variables, the offending page is the last listed's Warnings listed in blue.Touch as when using the not recommended ignoring techniques, it will compile, but warn of potential unexpected behaviours), Errors listed in red (this will not compile, and the build process halts). Note: Do not upload a zero byte file.

File Size must be small enough to fit in your Model's Flash size. See the Status Bar or your Datasheet for your model's Flash size. All paged Total Memory usage must be small enough to fit your model's HMI allotted SRAM. See the Status Bar or your Datasheet for your model's HMI allotted SRAM.

Due to the nature of flash, it is possible that a compiled Resize may be under the MB size (ie: 16777k bytes) and still be shy of the available and usable Flash on the Nextion Device. Resize may not upload on the file is too big – this is not a hardware error but the working volume of flash. Some allowance for wear-leveling and unusable Flash pages have to be made, and even more so over time.

2.16 Display / Programs.s Tabs

Use the Display Tab to show the Design Canvas

Use the Programs.s Tab to set project global variables and project start up code. Variable declarations are made first, followed by code, and finally the power on start page. Code after a page change to the start page can never be executed as the start page will never return back to the start to complete the section after page change line.

2.17 Status Bar

The Status Bar at the bottom contains three segments. The character encoding, the quick details of the Nextion Model selected, and the design Canvas mouse coordinates. Clicking on Encoding will launch the BOM.bpl tab of Device Settings. The Nextion Model details provide quick design specifications - limits of Project SRAM and Flash is useful to be mindful of.

3. Debug / Simulator Overview

1) Simulated Nextion ... goto>
2) Operations Menu ... goto>
3) Command Redirection ... goto>
4) Input Encoding ... goto>
5) Instruction Input ... goto>
6) Simulator Restart ... goto>
7) User MCU Return ... goto>
8) Input Selection ... goto>
9) Connected Nextion Identification ... goto>
10) Waveform Generator ... goto>
11) Waveform Generator Options ... goto>
12) Nextion Address ... goto>
13) Simulator Backlight and Sleep ... goto>
14) Saved Nextion Input ... goto>

3.1 Simulated Nextion

This is a simulation – this is not an emulation.

Purpose of the simulation is to aid in debugging.it commands

Timers will not be precision under any Windows OS

RTC is simulated, GPIO is not simulated

EEPROM .bi simulated with eeprom.bin in virtual EEPROM folder

microSD card is simulated with files in Virtual SD Card folder

Note: EEPROM generally allowes to a byte boundaries when writing

Users may write to any address, but should care for data until boundary.

3.2 Operations Menu

Synchronize RTC time and Reboot (for each Simulator and Device).

3.3 Command Redirection

Simulator only, Nextion device only, or both.

Only one Nextion device or User MCU can be connected at a time

When one is selected, the other is not available.

3.4 Input Encoding

Character Encoding to use for input

3.5 Instruction Input

Text command input of any non-block instructions (excludes if, for and while)

Use the CRC checkbox to send the CRC Encoder 0 with instructions

Toggle hex mode to ensure byte precision in input.

(Answers the question of how to input less frequently used characters)

3.6 Simulator Return

Any Return Data or print commands from Simulator will display here

Expected to be sufficient to aid in the debugging process

Not expected to be full basic logs (Simulator – not emulator)

View in Hex or String format

View Line by Line (LSI) terminations), or by Total bytes in Hex

Context Menu (right click) to: Copy HEX, Copy STR, Copy HEX+STR

3.7 User MCU Return

Any Return Data or print commands from Nextion/MCU will display here

Expected to be sufficient to aid in the debugging process

Not expected to be full basic logs (Simulator – not emulator)

View in Hex or String format

View Line by Line (LSI) terminations), or by Total bytes in Hex

Context Menu (right click) to: Copy HEX, Copy STR, Copy HEX+STR

3.8 Input Selection

Keyboard User is the default simulation input method.

Cut, Copy, Paste and Delete added to right click context menu.

Toggle to User MCU input to have user MCU interact with Simulator

Select Com Port of user MCU, MCU operating baud rate and then Start

When one Nextion device or User MCU can be connected at a time

When one is selected, the other is not available.

3.9 Connected Nextion Identification

When Nextion is connected to Simulator, portions of connect string is shown here.

3.10 Waveform Generator

Click here to show the Waveform Generator

3.11 Waveform Generator Options

Sinewave or random waveform input at selected intervals.

Expected to be sufficient to aid in the debugging process

Not expected to be an oscilloscope (Simulator – not emulator)

3.12 Nextion Address

Default is 0 – Address in normal mode, 254 to 3FFF in address mode.

Address will only apply to specialized advanced applications.

3.13 Simulator Backlight and Sleep

The current backlight value (255=Unlocked) while debugging

The current sleep state indicated by Yes (Sleep) or No (wake).

3.14 Saved Nextion Input

The Debug Simulator now has a storage points for saving input

Clicking the **S** box will allow you to choose where to store

Clicking a numbered box will recall the input stored in the chosen slot

4. Uploading your Project your Device

Once you have completed designing your HMI project in the Nextion Editor and tested it with the Debug Simulator, it is now time to test it on your actual Nextion Device. Note: With previous versions of the Nextion Editor, the Compile and Debug button buttons created the project TFT file in the Xcmpl folder, note this has changed in favour of outputting your ***.tft** file directly to microSD card for faster of project retrieval.

4.1 Uploading using a microSD card

To upload via microSD card, first use the **TFT file output** under the File menu to generate your TFT file to your microSD card. You need to ensure that your microSD card is direct formatted as FAT32, that there is only 1 ***.tft** file on the microSD card in the root folder, that the microSD card is less than 32GB in size (32GB microSD cards generally work), that the power to Nextion device is off when inserting or removing the microSD card, and that you power cycle for any firmware updates to occur after powering your Nextion device back on. Note: not all microSD cards are designed for embedded use. example: Ultra High Speed microSD cards for use with high speed digital cameras. Not all manufacturers adhere to the same standards. It is a matter of finding microSD cards that work for you in a reliable manner. As an example, We have had good successes with Kingston 32GB class 10 HC microSD cards. ... there are many many others that work well.

4.2 Uploading via Serial

Uploading over TTL Serial can be accomplished using the **Upload** toolbar button and selecting your configured COM port and baud rate. Nextion Editor Revisions 1.61 has been published to the Nextion blog section. This allows users to upload their ***.tft** files over Serial without the Nextion Editor. As this is an advanced topic, it will not be covered in depth here. Please refer to the published Nextion Upload Protocol v1.1

5. External Tools

5.1 Font Creator

The Nextion Editor.fnt Font Creator has undergone an overhaul to introduce proportional fonts with anti-aliasing. Height must be between 16 and 2re and **Custom** can be chosen to set a height not listed in the dropdown (between 16 and 256). Choosing Anti-aliasing of Hinted will produce and regenerate an anti-aliased font, leaving anti-aliased not selected will generate a mono-bit font. Previous embedded 12 ratio with width=57height has been replaced w flexisar of proportional fonts. Fixed width fonts can still be generated. Font Height is the font size specified in the Nextion Editor, and that you desire for any firmware updates to occur after powering your Nextion device back on. Note: not all microSD cards are designed for embedded use. example: Ultra High Speed microSD cards for use with high speed digital cameras. Not all manufacturers adhere to the same standards. It is a matter of finding microSD cards that work for you in a reliable manner. As an example, We have had good successes with Kingston 32GB class 10 HC microSD cards ... there are many many others that work well.

Font Height is the font size specified in the Nextion Editor, and that you desire for any firmware updates to occur after powering your Nextion device back on. Note: not all microSD cards are designed for embedded use. example: Ultra High Speed microSD cards for use with high speed digital cameras. Not all manufacturers adhere to the same standards. It is a matter of finding microSD cards that work for you in a reliable manner. As an example, We have had good successes with Kingston 32GB class 10 HC microSD cards ... there are many many others that work well.

Using the UTF-8 font has requirements that event code is UTF-8 and project Encoding is UTF-8, but for those that are preferring to use UTF-8 over single byte or double byte encodings. For example, The Font Creator generation a 2 font using user selected combinations of 142 UTF-8 subsets. Select Encoding as UTF-8 in the Font Creator and click on the language(sub) link near the bottom to launch the subset selections. Once your Language Choice selections are selected, click confirm and Generate font. (ensure Height, Encoding, Font, Antialiasing and Bold choices, and Font Name are done as usual)

5.2 Gmov Maker

GMovMaker is a new tool for assisting in creating animations. Ensure that your resources are of uniform size. GmovMaker will create the sequence of images (frames) in the order you create and render your frames with the timing set for each frame (Default of 100ms). Frame timing can be set between 10ms and 5000ms. The generated .gmov resource can then be added to your Nextion project as a single resource making your animations easy. GmovMaker will accept *.bmp, *.gif, *.jpg and *.png source files.

5.3 Videoblox

Videoblox is a new tool for the Intelligent Series used to create Audio Resource *.aaa files from your audio sources, and Video Resource *.video files from your video sources.

Videoblox will accept *.wav, *.mp3, *.mov, *.avi, *.mpeg, *.mpg, *.vob, *.wmv, *.mov, *.3gp, *.mp4 and *.wav audio source files.

Audio can be run from the microSD card for the Intelligent Series, see the .Rom attribute of the Audio Component for external file.

Videoblox will accept *.mkv, *.mpeg, *.mov, *.avi, *.mpeg, *.mpg, *.vob, *.wmv, *.mov, *.3gp, *.mp4 and *.wav audio source files.

Video can be run from the microSD card for the Intelligent Series, see the .Rom attribute of the Video Component for external file.

5.4 PictureBox

PictureBox is a new tool for the Intelligent Series used to create resources for the Exfiture components. Picture resources are then stored as rom or in the microSD card folder. Ensure to set the resource orientation the same as the proper orientation for your project. The tool will output your picture resource as an *.el file. PictureBox will accept *.bmp, *.jpg, *.jpeg, and *.png source files.

Copyright 2011 - 2021 ITEAD STUDIO All Rights Reserved