


# **Tao of Arduino**

**Chen-Hanson Ting**



**Offete Enterprises  
November 2011**

# **Tao of Arduino**

## **Contents**

<b>1.</b>	<b>eForth of Arduino</b>	<b>1</b>
<b>1.1</b>	<b>Arduino as a Firmware Development Platform</b>	<b>1</b>
<b>1.2</b>	<b>What is FORTH?</b>	<b>3</b>
<b>1.3</b>	<b>FORTH for Firmware Development</b>	<b>6</b>
<b>1.4</b>	<b>Arduino Tao Board</b>	<b>8</b>
<b>2.</b>	<b>328eForth for Arduino Uno</b>	<b>14</b>
<b>2.1</b>	<b>Introduction</b>	<b>14</b>
<b>2.2</b>	<b>Installing Tools</b>	<b>15</b>
<b>2.3</b>	<b>Assembling 328eForth</b>	<b>16</b>
<b>2.4</b>	<b>The Terminal Interface</b>	<b>20</b>
<b>2.5</b>	<b>Testing 328eForth on Arduino Uno</b>	<b>20</b>
<b>2.6</b>	<b>Learning More about eForth</b>	<b>23</b>
<b>3.</b>	<b>What eForth Does But Arduino Cannot</b>	<b>25</b>
<b>3.1</b>	<b>USART</b>	<b>26</b>
<b>3.2</b>	<b>GPIO Port B</b>	<b>27</b>
<b>3.3</b>	<b>Timer/Counter0 and Tone Generator</b>	<b>29</b>
<b>3.4</b>	<b>Timer/Counter1</b>	<b>30</b>
<b>3.5</b>	<b>ADC</b>	<b>32</b>
<b>3.6</b>	<b>Build a Turnkey Application</b>	<b>33</b>
<b>4.</b>	<b>Features in 328eForth Implementation</b>	<b>34</b>
<b>4.1</b>	<b>Addressing Memory</b>	<b>34</b>
<b>4.2</b>	<b>Flash Programming</b>	<b>34</b>
<b>4.3</b>	<b>Number Formats</b>	<b>35</b>
<b>4.4</b>	<b>Memory Spaces</b>	<b>35</b>
<b>4.5</b>	<b>Files</b>	<b>35</b>
<b>4.6</b>	<b>Case Sensitivity</b>	<b>36</b>
<b>4.7</b>	<b>What 328eForth Does Not Have</b>	<b>36</b>
<b>5.</b>	<b>328eForth Source Code</b>	<b>38</b>
<b>5.1</b>	<b>Virtual FORTH machine on ATmega328P</b>	<b>41</b>
<b>5.2</b>	<b>Common Functions</b>	<b>63</b>
<b>5.3</b>	<b>Input Output</b>	<b>78</b>
<b>5.4</b>	<b>Interpreter</b>	<b>00</b>
<b>5.5</b>	<b>Compiler</b>	<b>109</b>
<b>6.</b>	<b>Conclusions</b>	<b>133</b>
<b>Appendix</b>	<b>328eForth Commands</b>	<b>135</b>